# **DNS – Bind9 manager**

#### 1. Introduction

The Domain Name System is a hierarchical and decentralized naming system for computers, services, or other resources connected to the Internet or a private network.

In this Lab, you will set up a DNS service consisting of a primary server. Then you will study more closely how it works

### 2. Install Bind9 package

You install your DNS server on your gateway Virtual machine. Be sûr that your machine has a static IP address representing your LAN. This VM is called « ns » and its FQDN is « ns.ufaz.lab »

Once we have a static IP and have rebooted the Raspi, we can install Bind DNS.

# sudo apt-get install bind9

You will find all files in directory /etc/bind.

Your lab domain is "ufaz.lab". You need to announce two zones to Bind process. One for forward name resolution and one for reverse lookup.

### 2.1. Named zone configuration

Enter to the « named.conf.local » and add your name resolution zone called « ufaz.lab » and the reverse one « x.y.z.in-addr.arpa »

```
zone "ufaz.lab" {

type master;

notify no;

file "/etc/bind/db.lab";

};

zone "x.y.z.in-addr.arpa" {

type master;

notify no;

file "/etc/bind/db.reverse";

};
```

#### 2.2. The zone files

As announced in the "named.conf.local" file, you have one file per zone. The zone files contain all entries as a translation table for the names of the resources in the same zone.

# - /etc/bind/db.local file:

Complete the below file to resolve the reste of VM hosts of your plate-forme. Give a name for each VM

```
; BIND reverse data file for broadcast zone
$TTL 604800
@ IN SOA ns.ufaz.local. root.ifaz.local. (
               100 ; Serial
               6H; Refresh
               86400; Retry, temps entre de essais
               2419200 ; Expire
               604800); Negative Cache TTL
        NS ns.ufaz.local.
        MX 10 mail.ufaz.local.
ns1
       IN
               Α
                                              (x.x.x.x : IP address is the DNS server IP
                       X.X.X.X
address)
```

- /etc/bind/db.reverse file :

Consider 10.0.0.1 the DNS IP address, if we mappe dit to x.y.z.T. The reverse resolution of this address is represented by « T » and is a pointer to « ns.ufaz.lab » in the « db.reverse » file. With the knowledge that « x.y.z » the network prefix is used to identify the reverse zone in the « named.conf.local »

Complete this file to translate all IP addresses to their corresponding names

### 3. Syntax verification

Verify your syntax is working by using named-checkconf

# named-checkconf /etc/bind/named.conf.local

Also double check syntax on your « db.lab » file and all others you have setup, you would do the following.

# named-checkzone ufaz.lab /etc/bind/db.lab

Output we will look as below:

zone lab.local/IN: loaded serial <u>1</u> OK

the server configuration part is completed, you must restart the service

# systemctl restart bind9

Know you need to setup the clients you configured in your « db.local » file.

### 4. Configure clients

To complete the configuration, you update the /etc/resolv.conf file.

### search ufaz.lab

nameserver x.x.x.x

(x.x.x.x is the DNS IP address)

#### 5. DNS query test

You have many tools to make a DNS query, you use olny two: nslookup and dig CLI commands

#### Example:

nslookup ns.ufaz.lab

or

nslookup 8.8.8.8 (be sûre that you have access to Internet)

dig @IP\_of\_your\_DNS <u>www.google.com</u> ANY

#### test:

- Based on « dig » command, send a DNS query to ufaz.az to ask for mail server
- How you can get the SOA of this domain
- Look for the NS server of google.com
- With scapy create a script to send a DNS query to ufaz.az